

FIG. 1




FIG. 2





FIG. 3

FIG. 4

http://abcd/ef/gh.html.

FILE EDIT VIEW MOVE FAVORITE HELP

DEVICE NAME	PRODUCT NAME	NETWORK INTERFACE BOARD NAME	LOCATION	IP ADDRESS	MAC ADDRESS
DEVICE A	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE B	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE C	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE D	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE E	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE F	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE G	MODEL X	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE H	MODEL Y	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE I	MODEL Y	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE J	MODEL Y	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE K	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE L	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE M	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE N	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE O	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE P	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*
DEVICE Q	MODEL Z	MODEL *	ROOM*	192.168.16.*	0000850E000*

41 46 42 43 44 45

PAGE DISPLAYED INTRANET ZONE


FIG. 5

FIG. 6




FIG. 7




FIG. 8

FILE EDIT VIEW MOVE FAVORITE HELP

LOGOFFMANAGER MODEDEVICE LISTENVIRONMENT SETUPSUPPORT LINKMANUAL

DEVICE LIST DISPLAY SETUP

CHANGE TO: 83 OK CANCEL ?

SORT

☐ DEVICE NAME

☒ PRODUCT NAME

☐ NETWORK I/F BOARD NAME

☐ LOCATION

☐ NETWORK ADDRESS

☐ MAC ADDRESS

81

DISPLAY

☐ PRODUCT NAME

☒ NETWORK I/F BOARD NAME

☒ LOCATION

☒ NETWORK ADDRESS

☒ MAC ADDRESS

82

OXOX

FIG. 9

http://abcd/ef/gh.html. FILE EDIT VIEW MOVE FAVORITE HELP

DEVICE NAME	NETWORK INTERFACE BOARD NAME	LOCATION	IP ADDRESS	MAC ADDRESS
DEVICE A	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE B	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE C	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE D	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE E	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE F	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE G	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE H	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE I	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE J	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE K	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE L	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE M	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE N	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE O	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE P	MODEL *	ROOM *	192.168.16.*	0000850E000 *
DEVICE Q	MODEL *	ROOM *	192.168.16.*	0000850E000 *

91 92 93 94 95

PAGE DISPLAYED INTRANET ZONE

X
O
X
O

FIG. 11

FILE

EDIT

VIEW

MOVE

FAVORITE

HELP

70 LASER**70

LAST UPDATED : 1999/12/22 10:01:10

STATUS

PRINTER : NO PAPER, PLEASE SUPPLY A4-SIZE PAPER IN CASSETTE 1.

ERROR INFO

PAPER SUPPLY INFO

✓ PAPER TRAY

◇ FREE SIZE 23456

✓ CASSETTE 1

⊗ A4

✓ CASSETTE 2

⊗ LETTER 2345

✓ PAPER DECK

⊗ A4 23456

PAPER SUPPLY

PAPER TRAY

BIN 1

BIN 2

▶ BIN 3 0%

PAPER DELIVERY : NO DESIGNATION

ERROR INFO

PRINTER CONTROL

LOGOFF

MANAGER MODE

DEVICE LIST

DEVICE MANAGEMENT

STATUS

INFO

EQUIPMENT

NETWORK

JOB MANAGEMENT

ENVIRONMENT SETUP

SUPPORT LINK

MANUAL

OXOX

11 / 11